



Jeger Beton decorative effect is a unique solution that will lend your walls an exceptionally industrial character. Architectural concrete with a matte finish is recommended for use on interior walls, on virtually any type of substrates such as plasterwork, drywall or concrete.

You can do it yourself in one day!

## It's just 3 steps

Only 2 tools

a roller



Apply Jeger **Primer Beton** Black with a roller



Apply Jeger Primer Beton Black to a clean, dry, dust-free and degreased wall and let it dry for about 4 hours.





Mix Jeger Beton Black thoroughly before use. Do not dilute with water. Do not mix with other products. Apply with a Venetian trowel to the thickness of the grain and smooth. If you want to change the effect, after about 4 hours you can apply another coat and repeat the process. Apply at +8°C to +25°C at a relative humidity of max. 82%, avoid drafts. Allow to dry for about 12 h. After painting, wash the tools with warm water.

Protect the surface with Jeger Protector **Beton Black** 





To protect the coating and enhance the blackness on the dried surface, apply **Jeger Protector Beton Black** with a roller according to the instructions on the label. The varnish changes the color of the surface and allows for a deeper black with a matte finish.

Tips: If you want to create a concrete slab effect, apply Tape for imitating concrete slabs to the dried first layer of concrete in the areas separating the slabs from each other. Then apply a second layer of concrete and after approx. 30 minutes remove the tape, obtaining the pattern of the slabs. Gently smooth the entire surface.



Remember: If you need to use more than one pack of the product, mix the contents of all the packs together before applying. Check the effect on a small area before applying the varnish to the whole surface. The product is intended for interiors.

jeger.com



Global Point, ul. Rozwoju 3, Biskupice Podgórne, 55-040 Kobierzyce

